



---

The NitroOBD2 Chip box is very easy to use.

Plug the NitroOBD2 Chip box into the OBD2 connector of your car. Turn the ignition on for 30 seconds and then turn the engine on.

The NitroOBD2 Chip box settings are optimal and the best for your car. It will recognize your vehicle and your driving habits and adapt after approximately 200 km driving, and then it adjusts itself to match your car perfectly.

The NitroOBD2 Chip box works on the basis of changing the signal from the ECU. As a consequence, it changes the whole injection map.

The main difference between the NitroOBD2 Chip Tuning Box and Remapping tuning methods is that NitroOBD2 Chip Tuning Box is easily removable. After you have unplugged it from your vehicle, your vehicle will go back to the factory settings.

Installation and Calibration:

Pull the Car Key out from the ignition.

Find OBD2 connector in your car and plug in the NitroOBD2 Chip box.

Insert the key into the ignition and twist the key to the first stage. (Do not start the car).

Press the reset button on the NitroOBD2 Chip box for 5 seconds. After releasing the button, just wait for approximately 40-60 seconds. (The NitroOBD2 Chip box will communicate and establish a connection with the ECU).

Start up the engine.

You are now.